



Transtar NoMix Low VOC Tech Tip

Now that we have had customers using the product in their shops for a while, we have been getting helpful feedback that we want to share with all of our NoMix users.]

Basecoat

When first trying the NoMix Low VOC basecoat, the recommended mixing ratio on the can is 100:100. We find that adding more reducer and mixing 100:150 will result in an easier to apply basecoat that lays down better while still providing excellent coverage.

- a. *Adding more than the 150% reducer is not recommended as it will not improve the basecoat performance, but it will reduce the coverage rate of the basecoat and force application of more coats to achieve coverage.*
- b. *This will also result in a lower ready to spray cost of the color.*

***Note:** While this practice will improve the overall basecoat performance, it will also result in a higher ready to spray VOC level. Please check the regulations in your area before mixing the product in this manner to make sure you are in compliance.*

